

# 程式指南





















| 程式      | 溫度 (°C)        | 最高轉速 (rpm) | 最高洗衣重量 (公斤) | 最高乾衣重量 (公斤) | 洗滌劑抽屜隔層 |    |     | 選項 |     |      |      |        | 若選擇，則將於洗衣後乾衣 | 洗滌說明                                  |
|---------|----------------|------------|-------------|-------------|---------|----|-----|----|-----|------|------|--------|--------------|---------------------------------------|
|         |                |            |             |             | 預洗      | 洗衣 | 柔軟劑 | 預洗 | 加強洗 | 防皺功能 | 加強沖洗 | 彈性工作時間 |              |                                       |
|         |                |            |             |             |         |    |     |    |     |      |      |        |              |                                       |
| 棉質與彩色衣物 | 略有污垢的淺色衣物      | 冷洗         | 最高          | 7           | 4       | ✓  | ✓   | ✓  | ✓   | ✓    | ✓    | ✓      | 正常           | 冷洗、沖洗和以所選速度最後脫水                       |
|         | 正常污垢的淺色衣物      | 40°        | 最高          | 7           | 4       | ✓  | ✓   | ✓  | ✓   | ✓    | ✓    | ✓      | 正常           | 40°C洗滌、沖洗和以所選速度最後脫水                   |
|         | 正常污垢的淺色衣物      | 40°節能洗     | 最高          | 7           | 4       | ✓  | ✓   | ✓  | ✓   | ✓    | ✓    | ✓      | 正常           | 40°C洗滌、沖洗和以所選速度最後脫水                   |
|         | 正常污垢的深色衣物      | 60°        | 最高          | 7           | 4       | ✓  | ✓   | ✓  | ✓   | ✓    | ✓    | ✓      | 正常           | 60°C洗滌、沖洗和以所選速度最後脫水 (僅選擇「加強洗」選項的標準循環) |
|         | 嚴重污垢的深色衣物      | 90°        | 最高          | 7           | 4       | ✓  | ✓   | ✓  | ✓   | ✓    | ✓    | ✓      | 正常           | 90°C洗滌、沖洗和以所選速度最後脫水                   |
| 混合衣物    | 略有污垢的棉質和人造纖維衣物 | 冷洗         | 1200        | 3           | 3       | ✓  | ✓   | ✓  | ✓   | ✓    | ✓    | ✓      | 細緻衣物         | 冷洗、沖洗和以所選速度最後脫水                       |
| 羊毛衣物    | 略有污垢的衣物        | 30°        | 800         | 2           | -       | ✓  | ✓   | -  | -   | -    | -    | -      | -            | 30°C洗滌、沖洗和以所選速度最後脫水                   |
| 排水和脫水   |                | -          | 最高          | 7           | -       | -  | -   | -  | -   | ✓    | -    | ✓      | -            | 僅排水，或排水和以所選速度最後脫水                     |
| 人造纖維衣物  | 略有污垢的衣物        | 40°        | 1000        | 3,5         | 3,5     | ✓  | ✓   | ✓  | ✓   | -    | ✓    | ✓      | 細緻衣物         | 40°C洗滌、沖洗和以所選速度最後脫水                   |
|         | 正常污垢的衣物        | 60°        | 1000        | 3,5         | 3,5     | ✓  | ✓   | ✓  | ✓   | -    | ✓    | ✓      | 細緻衣物         | 60°C洗滌、沖洗和以所選速度最後脫水                   |
| 15'快洗   | 柔軟精清洗輕棉或細緻布料   | 30°        | 800         | 2           | -       | ✓  | ✓   | -  | -   | -    | -    | -      | -            | 30°C洗滌、沖洗和以所選速度最後脫水                   |
| 運動衣物    | 略有污垢的衣物        | 30°        | 800         | 2           | 2       | -  | ✓   | ✓  | -   | ✓    | ✓    | ✓      | -            | 30°C洗滌、沖洗和以所選速度最後脫水                   |
| 乾衣      | 細緻衣物           | 60°        | 最高          | -           | 3       | -  | -   | -  | -   | -    | -    | -      | -            | 人造纖維和細緻衣物的溫柔乾衣                        |
|         | 正常             | 90°        | 最高          | -           | 4       | -  | -   | -  | -   | -    | -    | -      | -            | 棉質衣物的正常乾衣                             |
|         | 清洗             | -          | -           | -           | -       | -  | -   | -  | -   | -    | -    | -      | -            | 乾衣系統的清洗循環                             |

✓ 通用選擇



: 無法同時選擇的選項

## PROGRAM GUIDE

| Programs   | Temp.<br>(°C)   | Max. Spin<br>(rpm) | Max. washing<br>load (kg) | Max. drying<br>load (kg) | Detergent drawer compartments   |   |   | Options   |   |   |   |   | Drying after<br>wash if<br>selected | Wash program description |   |
|--|---|--------------------|---------------------------|--------------------------|---|---|---|---|---|---|---|---|-------------------------------------|--------------------------|---|
|  |   |                    |                           |                          | Prewash   | Wash  | Conditioner   | Prewash   | Intensive   | Easy<br>Iron  | Extra rinse   | Flexi<br>Time   |                                     |                          |   |
|  |   |                    |                           |                          |  |  |  |  |  |  |  |  |                                     |                          |   |
| Cotton and<br>coloureds  | Delicate coloureds<br>with light dirt   | cold               | Max                       | 7                        | 4   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓                                   | Normal                   | Cold wash, rinses and final spin at the selected speed  |
|  +      | Delicate coloureds<br>with normal dirt  | 40°                | Max                       | 7                        | 4   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓                                   | Normal                   | Wash at 40°C, rinses and final spin at the selected speed   |
|  | Delicate coloureds<br>with normal dirt  | 40°eco             | Max                       | 7                        | 4   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓                                   | Normal                   | Wash at 40°C, rinses and final spin at the selected speed   |
|  | Tough coloureds with<br>normal dirt   | 60°                | Max                       | 7                        | 4   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓                                   | Normal                   | Wash at 60°C, rinses and final spin at the selected speed<br>(Standard cycle with only "intensive" option selected) |
|  | Tough coloureds with<br>heavy dirt  | 90°                | Max                       | 7                        | 4   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓                                   | Normal                   | Wash at 90°C, rinses and final spin at the selected speed   |
| Mix  | Cotton and synthetics<br>with light dirt  | cold               | 1200                      | 3                        | 3   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓   | ✓                                   | Delicate                 | Cold wash, rinses and final spin at the selected speed  |
| Wool    | Items with light dirt   | 30°                | 800                       | 2                        | -   | -   | ✓   | ✓   | -   | -   | -   | -   | -                                   | -                        | Wash at 30°C, rinses and final spin at the selected speed   |
| Pump-out and spin  |  +  | -                  | Max                       | 7                        | -   | -   | -   | -   | -   | ✓   | -   | ✓   | -                                   | -                        | Pump-out only, or pump-out and final spin at the selected speed   |
| Synthetics   | Items with light dirt   | 40°                | 1000                      | 3,5                      | 3,5   | ✓   | ✓   | ✓   | ✓   | -   | ✓   | ✓   | ✓                                   | Delicate                 | Wash at 40°C, rinses and final spin at the selected speed   |
|  +  | Items with normal dirt  | 60°                | 1000                      | 3,5                      | 3,5   | ✓   | ✓   | ✓   | ✓   | -   | ✓   | ✓   | ✓                                   | Delicate                 | Wash at 60°C, rinses and final spin at the selected speed   |
| Rapid 15'  | Light cotton or delicate<br>fabrics for refreshing  | 30°                | 800                       | 2                        | -   | -   | ✓   | ✓   | -   | -   | -   | -   | -                                   | -                        | Wash at 30°C, rinses and final spin at the selected speed   |
| Sport   | Items with light dirt   | 30°                | 800                       | 2                        | 2   | -   | ✓   | ✓   | -   | ✓   | -   | ✓   | ✓                                   | -                        | Wash at 30°C, rinses and final spin at the selected speed   |
| Drying   | Delicate   | 60°                | Max                       | -                        | 3   | -   | -   | -   | -   | -   | -   | -   | -                                   | -                        | Delicate drying for synthetic and delicate items  |
|   | Normal   | 90°                | Max                       | -                        | 4   | -   | -   | -   | -   | -   | -   | -   | -                                   | -                        | Normal drying for cotton items  |
|  | Clean    | -                  | -                         | -                        | -   | -   | -   | -   | -   | -   | -   | -   | -                                   | -                        | Drying circuit cleaning cycle   |

✓: Option available



: Options which cannot be selected simultaneously